

新潟西港

NIIGATANISHIKO

2024 年

Table with columns for months (1月, 2月, 3月, 4月, 5月, 6月), days (日), and tide data (満潮, 干潮) including time and height in cm.

潮位表基準面の零点: 平均海面下 17.0 (cm)

# 新潟西港

NIIGATANISHIKO

2024 年

満潮					干潮					満潮					干潮																		
日	時	分	cm	時	分	cm	時	分	cm	時	分	cm	時	分	cm	日	時	分	cm	時	分	cm	時	分	cm								
7月	1	9	53	31			3	31	20	17	32	11			10月	1	2	29	30	13	40	35	7	46	23	20	48	18					
	2	0	54	26			3	43	25	18	38	10			2	2	35	30	14	27	34	8	20	20	21	10	19						
	3	11	7	38						19	36	9			3	朔	2	43	30	15	14	33	8	55	18	21	29	20					
	4	11	52	40						20	29	9			4	2	51	31	16	2	33	9	31	16	21	44	23						
	5									21	18	9			5	3	1	32	16	51	32	10	9	15	21	56	25						
	6	朔			13	32	42			22	5	9			6	3	13	34	17	42	32	10	48	14	22	0	27						
	7				14	21	42			22	48	9			7	3	31	36	18	38	32	11	29	15	21	56	30						
	8	6	5	31				8	23	30	23	29	9		8	3	52	37								12	14	15					
	9	6	34	29				9	11	28					9	4	18	38								13	7	16					
	10	7	3	28				0	5	10	10	6	26		10	4	49	38								14	13	16					
	11				17	14	31			0	37	11	11	25	25	11	上弦	5	32	37						15	34	16					
	12	7	51	27				1	2	13	12	56	23		12	6	57	35								16	55	14					
	13	8	7	27				1	20	16	14	9	21		13	9	7	34								18	0	13					
	14	上弦	8	19	29			1	28	20	15	19	20		14	1	39	29			10	51	34			5	27	27					
	15	8	32	32				1	22	23	16	28	19		15	1	31	28			12	11	34			6	22	22					
	16										17	30	18		16	望	1	35	28			13	23	35			7	14	17				
	17										18	24	17		17	1	47	29			14	34	35			8	8	12					
	18										19	13	15		18	2	6	32			15	44	35			9	3	8					
	19										20	1	14		19	2	32	35			16	51	34			9	58	6					
	20										20	50	12		20	3	2	38			17	57	34			10	53	6					
	21	望									21	39	10		21	3	36	40			19	10	32			11	48	7					
	22		5	10	34			7	40	32	22	27	8		22	4	13	40			4	13	40			12	47	9					
	23		5	35	32			8	33	30	23	13	7		23	4	54	39			5	4	39			13	51	11					
	24		6	0	30			9	34	27	23	57	9		24	5	42	37			6	5	42			15	5	13					
	25		6	25	30			10	54	24					25	6	52	34			6	52	34			16	21	14					
	26		6	50	30			0	36	12	12	18	21		26	1	44	30			43	31			4	47	30						
	27		7	15	31			1	12	16	13	31	19		27	1	14	29			10	32	29			5	55	26					
	28		7	43	34			1	41	21	14	44	18		28	1	5	27			11	50	28			6	35	22					
	29		8	15	37			1	53	27	16	3	17		29	1	4	27			12	53	28			7	8	19					
	30		8	56	40						17	26	17		30	1	7	27			13	49	28			7	38	15					
	31		9	46	42						18	39	16		31	1	13	28			14	42	28			8	9	13					
																											20	3	21				
8月	1		10	44	44						19	38	16		11月	1	朔	1	23	30	15	31	29			8	42	11	20	22	23		
	2		11	45	45						20	29	16		2	1	37	32			16	18	30			9	16	10	20	40	25		
	3										21	14	16		3	1	57	34			17	4	30			9	53	9	20	55	27		
	4	朔	4	42	36			7	1	35	21	55	15		4	2	21	35			17	52	30			10	31	9	21	7	28		
	5		4	53	34			7	51	32	22	31	15		5	2	49	36			18	46	30			11	13	9	21	13	29		
	6		5	10	33			8	38	30	23	2	15		6	3	20	36											12	0	9		
	7		5	30	32			9	28	28	23	29	15		7	3	56	36											12	52	9		
	8		5	48	31			10	24	26	23	51	17		8	4	38	34											13	52	9		
	9		6	3	31			11	26	24					8	上弦	5	37	32										14	59	9		
	10		6	13	31			0	7	20	12	25	23		10	7	9	29											16	6	9		
	11		6	20	33			0	13	23	13	21	22		11	0	4	25			9	10	27			4	7	23	17	7	10		
	12		6	31	36			0	3	27	14	21	22			23	56	24															
	13	上弦	6	54	38						15	30	22		12	10	57	27															
	14		7	30	40						16	47	22		13	0	2	25			12	25	27										
	15		8	23	42						17	57	20		14	0	18	27			13	48	29										
	16		9	33	43						18	56	18		15	0	41	30			15	4	30										
	17		10	50	44						19	48	16		16	望	1	11	34			16	11	31			8	59	2	20	23	26	
	18										20	38	13		17	1	46	37			17	12	31			9	52	1	20	39	28		
	19		4	5	35			6	57	34	21	25	11		18	2	26	38			18	12	30			10	44	2	20	51	29		
	20	望	4	18	33			7	51	30	22	10	11		19	3	9	39									11	37	3				
	21		4	35	32			8	50	26	22	51	12		20	3	54	38															
	22		4	54	32			9	58	22	23	29	15		21	4	40	35															
	23		5	14	33			11	8	19					22	5	29	32															
	24		5	36	34			0	2	19	12	14	17		23	6	25	28			23	32	24										
	25		6	1	37			0	29	25	13	19	16		24	7	53	24			23	27	23										
	26	下弦	6	32	39			0	36	30	14	29	17		25	10	0	21			23	30	23										
	27		7	11	41						15	51	18		26	11	41	20			23	34	24										
	28		8	6	42						17	22	19		27	13	6	21			23	42	25										
	29		9	22	43						18	36	19		28	14	17	22			23	55	27										
	30		10	43	43						19	33	19		29						15	12	24										
	31		11	52	43						20	19	18		30	0	15	30			15	56	26										
9月	1		3	39	36			6	48	34	20	57	18		12月	1	朔	0	42	32	16	36	27			9	2	5	19	43	26		
	2		3	41	34			7	30	31	21	30	17		2	1	15	33			17	16	28			9	41	4	20	11	26		
	3	朔	3	51	33			8	11	28	21	58	17		3	1	51	34			17	59	27			10	22	3	20	35	26		
	4		4	3	32			8	54	25	22	23	18		4	2	31	34															
	5		4	15	31			9	38	23	22	43	19		5	3	14	33															
	6		4	25	32			10	23	21	22	58	22		6	4	1	32															