

赤羽根

AKABANE

2020 年

Table with columns for month, day, tide type (満潮, 干潮), time (時), and height (分, cm). It provides detailed tidal data for each day of the year 2020.

潮位表基準面の零点: 平均海面下 105.0 (cm)

赤羽根

AKABANE

2020年

日	満潮				干潮				日	満潮				干潮																	
	時	分	cm	時	分	cm	時	分		cm	時	分	cm	時	分	cm	時	分	cm												
7月	1	2	128	162	15	8	151	.	8	27	50	20	30	97	10月	1	5	2	174	17	35	178	.	11	20	47	23	32	58		
	2	19	165	16	14	162	.	9	21	35	21	35	102	2		望	5	35	179	17	56	178	.	11	47	51	23	58	51		
	3	3	8	169	17	8	172	.	10	10	22	22	31	103		3	6	7	180	18	17	178	.				12	13	57		
	4	3	55	173	17	55	178	.	10	55	14	22	19	103		4	6	40	179	18	37	176	.	0	25	45	12	39	65		
	5	望	4	38	175	18	37	180	.	11	38	10					5	7	13	175	18	57	172	.	0	53	43	13	4	74	
	6	5	20	176	19	16	179	.	0	2	102	12	19	10		6	7	49	168	19	18	167	.	1	22	42	13	30	85		
	7	6	0	174	19	52	176	.	0	41	101	12	57	14		7	8	28	160	19	39	161	.	1	54	45	13	58	95		
	8	6	39	170	20	26	171	.	1	18	99	13	33	22		8	9	15	150	20	1	153	.	2	30	50	14	30	106		
	9	7	18	164	20	59	166	.	1	55	97	14	8	33		9	10	22	142	20	30	143	.	3	16	56	15	15	117		
	10	7	59	156	21	31	161	.	2	34	96	14	42	45		10	下弦	12	14	138	21	26	133	.	4	23	63	17	10	125	
	11	8	44	146	22	6	157	.	3	18	94	15	17	58		11				14	6	146	.	6	1	64	20	11	118		
	12	9	40	136	22	44	153	.	4	11	92	15	55	72		12	0	21	129	15	1	157	.	7	35	58	21	2	104		
	13	下弦	10	55	128	23	29	150	.	5	16	88	16	43		86	13	2	7	141	15	38	168	.	8	43	47	21	37	86	
	14				12	35	126	.	6	28	81	17	49	99		14	3	11	158	16	11	177	.	9	36	38	22	11	68		
	15		0	23	149	14	15	132	.	7	35	71	19	14		107	15	4	3	174	16	42	185	.	10	21	33	22	46	49	
	16	1	20	150	15	28	143	.	8	30	59	20	35	111		16	4	51	188	17	13	190	.	11	3	35	23	22	33		
	17	2	13	153	16	19	154	.	9	17	46	21	38	110		17	朔	5	38	196	17	43	192	.	11	43	43	23	59	21	
	18	3	1	157	17	1	164	.	10	0	34	22	26	107		18	6	25	198	18	12	190	.				12	22	56		
	19	3	45	163	17	39	173	.	10	41	22	23	7	104		19	7	12	192	18	42	185	.	0	37	15	13	0	72		
	20	4	27	169	18	17	179	.	11	21	13	23	46	100		20	8	2	182	19	11	177	.	1	18	15	13	38	89		
	21	朔	5	9	175	18	54	182	.			12	2	7		21	8	56	168	19	41	167	.	2	0	22	14	18	104		
	22	5	52	178	19	31	183	.	0	24	96	12	43	6		22	10	2	154	20	14	154	.	2	48	34	15	6	116		
	23	6	37	178	20	8	181	.	1	4	91	13	24	11		23	上弦	11	31	145	20	59	139	.	3	46	49	16	28	124	
	24	7	24	175	20	45	178	.	1	46	87	14	5	21		24	13	18	144	22	59	127	.	5	6	61	19	9	120		
	25	8	16	167	21	22	174	.	2	32	83	14	48	36		25				14	26	149	.	6	47	68	20	36	106		
	26	9	14	157	22	0	168	.	3	23	79	15	32	55		26	1	27	128	15	7	154	.	8	9	67	21	14	90		
	27	上弦	10	24	147	22	41	163	.	4	22	75	16	21		76	27	2	44	138	15	38	160	.	9	4	64	21	45	76	
	28	11	56	139	23	31	159	.	5	32	70	17	21	96		28	3	35	149	16	5	164	.	9	46	62	22	12	62		
	29				13	47	141	.	6	50	62	18	44	111		29	4	15	159	16	29	168	.	10	20	61	22	39	50		
	30		0	33	156	15	21	150	.	8	5	52	20	21		117	30	4	50	167	16	52	171	.	10	51	62	23	5	40	
	31	1	44	157	16	23	162	.	9	9	41	21	39	116		31	望	5	24	173	17	14	173	.	11	20	66	23	32	32	
8月	1	2	50	161	17	9	171	.	10	2	31	22	33	110	11月	1	5	57	176	17	36	173	.	11	48	71	23	59	27		
	2	3	46	166	17	47	177	.	10	48	23	23	15	104		2	6	30	176	17	58	171	.				12	15	77		
	3	4	34	172	18	21	180	.	11	29	19	23	51	97		3	7	3	174	18	20	168	.	0	28	24	12	43	84		
	4	望	5	16	175	18	52	180	.			12	5	19		4	7	39	168	18	43	163	.	0	58	24	13	11	91		
	5	5	54	176	19	20	178	.	0	23	92	12	39	23		5	8	18	161	19	8	157	.	1	31	28	13	43	98		
	6	6	30	175	19	46	175	.	0	55	87	13	9	30		6	9	5	153	19	36	148	.	2	8	34	14	20	106		
	7	7	8	171	20	12	172	.	1	26	83	13	38	39		7	10	7	145	20	14	138	.	2	54	41	15	17	113		
	8	7	43	164	20	37	168	.	1	59	81	14	8	51		8	下弦	11	32	142	21	30	127	.	3	55	50	17	7	116	
	9	8	23	155	21	2	164	.	2	35	79	14	35	64		9	13	2	145	21	2	145	.	5	20	56	19	21	106		
	10	9	10	145	21	30	159	.	3	17	78	15	6	79		10	0	1	124	14	4	153	.	6	51	56	20	23	89		
	11	下弦	10	10	136	22	3	153	.	4	7	78	15	41		94	11	1	48	135	14	48	162	.	8	5	53	21	5	68	
	12		11	37	130	22	47	148	.	5	10	77	16	33		108	12	2	58	151	15	25	170	.	9	4	51	21	43	47	
	13		13	40	132	23	57	144	.	6	26	72	18	9		119	13	3	54	167	15	59	177	.	9	54	51	22	22	27	
	14				15	15	143	.	7	42	64	20	14	122		14	4	45	180	16	33	182	.	10	39	56	23	0	11		
	15		1	23	145	16	7	155	.	8	45	52	21	30		117	15	朔	5	34	188	17	5	184	.	11	22	64	23	40	0
	16	2	33	151	16	46	167	.	9	37	38	22	17	109		16	6	22	190	17	38	183	.				12	3	74		
	17	3	29	161	17	21	176	.	10	23	25	22	56	100		17	7	10	185	18	11	179	.	0	21	-4	12	43	85		
	18	朔	4	18	171	17	55	184	.	11	6	15	23	32		91	18	7	59	176	18	45	171	.	1	2	0	13	24	95	
	19	5	4	181	18	28	188	.	11	47	9					19	8	50	165	19	20	160	.	1	45	9	14	8	103		
	20	5	49	187	19	1	190	.	0	8	81	12	27	10		20	9	45	154	20	0	147	.	2	31	23	14	59	109		
	21	6	35	189	19	34	189	.	0	46	73	13	6	18		21	上弦	10	49	145	20	52	133	.	3	21	38	16	10	111	
	22	7	22	185	20	5	185	.	1	25	65	13	45	32		22	12	1	141	22	26	120	.	4	21	53	17	59	107		
	23	8	12	177	20	36	179	.	2	7	60	14	23	52		23	10	7	145	22	14	138	.	5	37	65	19	36	95		
	24	9	8	164	21	8	172	.	2	53	58	15	2	74		24	0	37	117	14	1	144	.	6	59	71	20	30	80		
	25	上弦	10	15	150	21	42	164	.	3	45	59	15	45		96	25	2	12	124	14	41	148	.	8	9	74	21	8	64	
	26	11	52	141	22	27	155	.	4	51	61	16	44	115		26	3	13	134	15	13	153	.	9	2	75	21	41	50		
	27	14	4	142	23	45	147	.	6	17	62	18	36	127		27	4	0	145	15	42	157	.	9	45	75	22	11	37		
	28				15	33	153	.	7	49	58	20	46	124		28	4	39	154	16	10	160	.	10	22	76	22	40	26		
	29		1	32	147	16	20	163	.	9	2	49	21	51		114	29	5	15	162	16	36	163	.	10	55	78	23	10	17	
	30		2	53	153	16	55	171	.	9	55	41	22	31		1															